



New 6-Axis Servo Motor Controller Click <u>here</u> for high res image file

# **PI PRESS RELEASE**

# Compact 6-Axis Motion Controller for High Precision Positioning Applications in Industry and Research

# *PI's new cost-efficient servo motor controller drives 6 and 4 axis motion systems.*

October 2017, Auburn, MA – Precision positioning systems industry leader PI (Physik Instrumente) has released a new 6-axis servo motor controller – the C-884.6DC. Most modern precision motion systems are driven by servo motors, because they provide high torque, fast acceleration, smooth motion with a wide dynamic speed range, and fast start stop performance.

# Versatile, Compact Motion Controller

PI's compact C-884 DC motion controller can run brushless servo motors and traditional DC motors with closed loop feedback provided by incremental encoders and absolute encoders (BiSS protocol). USB, TCP/IP and RS-232 interfaces are standard for command communication. Additional interfaces such as programmable analog and digital I/O lines, an SPI display port and joystick port are also included.

The dual-core architecture provides for increased performance and flexibility by separating command processing and position servo control functions.

# **Features and Benefits**

- Cost efficient 6-Axis / 4-Axis PID precision servo motor controller
- Position feedback: Incremental and absolute-measuring encoders (no referencing)
- Motor types: Brushless servo motors and traditional DC motors
- Trapezoidal velocity profile
- Point-to-point motion, vector motion, user-definable trajectories
- Powerful Python macro command language, nonvolatile storage for stand-alone operation
- Data recorder for detailed motion system analysis
- ID chip detection for fast start-up
- Extensive software support, e.g., for LabVIEW, MATLAB, C, C++, C#, VB.NET, Python

MOTION I POSITIONING



### Specifications, Datasheet, More Information >

http://www.pi-usa.us/products/Motor Controllers/Motor Controller Precision Positioner.php#C884

#### **Standard and Custom**

PI has in-house engineered solutions with over 4 decades of experience working with customers to provide products that meet application demands, and can quickly modify existing product designs or provide a fully customized OEM part to fit the exact requirements of the application.

#### USA / Canada

http://www.pi-usa.us | info@pi-usa.us East (508) 832-3456 Midwest (508) 832-3456 West (949) 679-9191 (LA Area & Mexico) (408) 533-0973 (Silicon Valley/Bay Area)

### About PI

PI is a leading manufacturer of air bearing stages, piezoelectric solutions, precision motion control equipment, and hexapod parallel-kinematics for semiconductor applications, photonics, bio-nano-technology, and medical engineering. PI has been developing and manufacturing standard & custom precision products with piezoceramic and electromagnetic drives for 4 decades. The company has been ISO 9001 certified since 1994 and provides innovative, high-quality solutions for OEM and research. The PI group employs more than 1,000 people worldwide in 15 subsidiaries and R&D / engineering centers on 3 continents.

> <u>READ the PI Tech Blog</u>

> WATCH PI Videos on YouTube

> FOLLOW PI on Twitter