

E-517 Digital Piezo Controller Operation Module

Wave Generator, Data Recorder, Display, Multiple Interfaces, for E-500 System



The E-517 piezo display and D/A converter module, provides USB and TCP/IP connectivity

- Low-Noise 24-bit D/A Converter
- Sample Rate 25 kHz
- TCP/IP, USB, IEEE 488 and RS-232 Interfaces
- 6-Digit Display for Voltage and Position
- 1- & 3-Channel Versions
- Wave Generator with Programmable Trigger-I/O
- Module for E-500 Piezo Controller Rack

The E-517 is a microprocessor controlled interface and display module for the E-500 piezo controller system (see p. 2-142). It is equipped with low-noise, 24-bit D/A converters and can be

controlled through four digital interfaces: TCP/IP, USB, RS-232 and IEEE 488 (GPIB).

Alternatively, stand-alone operation is possible by uploading

Ordering Information

E-517.i1
Interface / Display Module,
24 Bit D/A, TCP/IP, USB, RS-232,
Single Channel

E-517.i3
Interface / Display Module,
24 Bit D/A, TCP/IP, USB, RS-232,
3 Channels

Ask about custom designs!

macro command sequences to the internal non-volatile memory. For manual control a track-ball interface is provided. An LCD display indicates position or operating voltages of the individual channels / axes.

Wave Generator

The integrated wave generator can output periodic motion profiles. In addition to sine and triangle waves, arbitrary, user-defined motion profiles can be created and stored.

Extensive Software Support

The controllers are delivered with Windows operating software. Comprehensive DLLs and LabVIEW drivers are available for automated control.

Technical Data

Model	E-517.i1	E-517.i3
Function	Digital operation module	Digital operation module
Channels	1	3
Processor	DSP 60 MHz	DSP 60 MHz
Sampling rate, sensor	25 kHz, 8-times oversampling	25 kHz, 8-times oversampling
Thermal drift	Stability: 0.2 mV	Stability: 0.2 mV
Linearity @ nominal range	0.01 %	0.01 %
Resolution	DAC: 24 bit, ± 12 V ADC: 18 bit, sampling	DAC: 24 bit, ± 12 V ADC: 18 bit, sampling
Interfaces and operation		
Interfaces/communication	Ethernet (TCP/IP), USB, RS-232, IEEE 488	Ethernet (TCP/IP), USB, RS-232, IEEE 488
I/O ports	1 trigger input 1 trigger output 5 V MDR14 connector	3 trigger inputs 3 trigger outputs 5 V MDR14 connector
Command set	PI General Command Set (GCS)	PI General Command Set (GCS)
User software	PIMikroMove™	PIMikroMove™
Software drivers	Lab VIEW drivers, Windows and Linux Libraries (DLL)	Lab VIEW drivers, Windows and Linux Libraries (DLL)
Supported functionality	Wave generator, data recorder, macro programming	Wave generator, data recorder, macro programming
Display	LCD display for monitor signals (position and voltage), states and trackball menus	LCD display for monitor signals (position and voltage), states and trackball menus
Manual control	Operation via trackball	Operation via trackball
Miscellaneous		
Operating temperature range	+5 to +50° C	+5 to +50° C
Dimensions	21HP / 3U	21HP / 3U
Mass	0.37 kg	0.37 kg
Operating voltage	E-500 system	E-500 system

Linear Actuators & Motors**Nanopositioning / Piezoelectrics**Piezo Flexure Stages /
High-Speed Scanning Systems

Linear

Vertical & Tip/Tilt

2- and 3-Axis

6-Axis

Fast Steering Mirrors /
Active Optics**Piezo Drivers /
Servo Controllers**

Single-Channel

Multi-Channel

Modular

Accessories

Piezoelectrics in Positioning

Nanometrology**Micropositioning****Index**